



Deutsch	1
English	9
Nederlands	18
Français	26
Español	35
Português	43
Italiano	52
Dansk	60
Svenska	69
Norsk	77
Suomi	85
Eesti	93
Latviešu	101
Lietuvių	109
Polski	118
Česky	126
Slovenčina	134
Magyar	143
Slovenščina	151
Hrvatski	159
Srpski	168
Українська	176
Български	185
Română	194
Ελληνικά	202
Türkçe	211
عربي	220
繁體中文	229
中文	236

VC 5-A22

3.6 Indication of overloading and overheating

The power tool is equipped with an electronic system to protect against overloading and overheating. The power tool switches itself off automatically in the event of overloading or overheating. After releasing the control switch, the power tool may not restart immediately when the switch is pressed again (while the power tool is cooling down).

4 Technical data

	VC 5-A22
Rated voltage (DC)	21.6 V
Rated current input	16 A
Weight in accordance with EPTA-Procedure 01 (measured with B225.2)	5.2 kg
Ambient temperature	-17 °C ... 60 °C
Storage temperature	-20 °C ... 70 °C

4.1 Noise and vibration information, measured in accordance with EN 60335-2-69

	VC 5-A22
Sound pressure level (L_{pA})	70.9 dB(A)
Sound power level (L_{WA})	85.2 dB(A)
Uncertainty	2.4 dB(A)
Vibration emission value (a_h)	< 2.5 m/s ²
Uncertainty (K)	Is taken into account in the stated value

5 Operation

5.1 Preparations at the workplace

Observe the safety instructions and warnings in this documentation and on the product.
WARNING The appliance may be operated only by authorized, trained personnel.

5.1.1 Charging the battery

1. Before charging the battery, read the operating instructions for the charger.
2. Make sure that the contacts on the battery and the contacts on the charger are clean and dry.
3. Use an approved charger to charge the battery. → page 12

5.1.2 Inserting the battery



WARNING

Risk of injury by short circuit or falling battery!

- ▶ Before inserting the battery, make sure that the contacts on the battery and the contacts on the product are free of foreign matter.
- ▶ Make sure that the battery always engages correctly.

1. Charge the battery fully before using it for the first time.
2. Push the battery into the product until it engages with an audible click.
3. Check that the battery is seated securely.

5.1.3 Removing the battery

1. Press the battery release buttons.
2. Remove the battery from the tool.

5.1.4 Changing the filter bag

1. Switch the appliance off.
2. Open the two catches.
3. Lift the suction head off the waste material container.

