



SL 6-A22

English

4 Technical data

	SL 6-A22
Voltage	21.6 V
Brightness	3,000 lm
Weight	3.2 kg

4.1 Battery

Battery operating voltage	21.6 V
Ambient temperature for operation	-17 °C ... 60 °C
Storage temperature	-20 °C ... 40 °C
Battery charging starting temperature	-10 °C ... 45 °C

5 Operation

5.1 Preparations at the workplace

CAUTION

Risk of injury by inadvertent starting!

- ▶ Before inserting the battery, make sure that the product is switched off.
- ▶ Remove the battery before making any adjustments to the power tool or before changing accessories.

Observe the safety instructions and warnings in this documentation and on the product.

5.1.1 Inserting the battery

CAUTION

Risk of injury by short circuit or falling battery!

- ▶ Before inserting the battery, make sure that the contacts on the battery and the contacts on the product are free of foreign matter.
- ▶ Make sure that the battery always engages correctly.

1. Charge the battery fully before using it for the first time.
2. Push the battery into the battery holder until it engages with an audible click.
3. Check that the battery is seated securely.

5.1.2 Removing the battery

1. Press the release buttons on the battery.
2. Pull the battery out of its holder in the device.

5.1.3 Charging the battery

1. Before charging the battery, read the operating instructions for the charger.

6 English

2. Make sure that the contacts on the battery and the contacts on the charger are clean and dry.
3. Use an approved charger to charge the battery.

5.1.4 Switching on

i Whenever you engage the product on the universal hook or mount it on a tripod, make sure that the product is secure.



- ▶ Select a mode by pressing the 4-mode switch.

5.1.5 Turning the lamp head

⚠ CAUTION

Risk of damage to the eyes (the retina). Looking directly into the lamp presents a risk of damage to the eyes (the retina).

- ▶ Do not direct the lamp at yourself or at anyone else.
- ▶ Do not, under any circumstances, look into the lamp.

⚠ CAUTION

There is a risk of crushing fingers in the joint area When the lamp head is being turned, there is a risk of the fingers being caught between the support leg and the casing.

- ▶ Wear protective gloves.

i The multi-position hinge and the lamp head can be turned in either direction along the axis. Do not attempt to force the lamp head past the end stops.